

Iona Preparatory School -- Science Department

Electronics and Robotics 2015-2016

Revised June 27, 2015

First assignment: Install SimpleIDE on your computer.

To install Simple IDE on a Windows computer:

1. Go to <http://learn.parallax.com/propeller-c-set-simpleide/windows>
2. Click on the link to download SimpleIDE 1.0 RC2 for Windows
3. Install Simple IDE as directed. At the same time you will be instructed to download and install FTDI drivers. Follow those directions.
4. STOP where it says "Connect your board and run a test program" You cannot run the program yet because you do not have the hardware. We will do that in class.

To install Simple IDE on a MAC:

1. Go to <http://learn.parallax.com/propeller-c-set-simpleide/mac>
2. Follow the instructions there regarding installation of the VCP driver. You must install the correct driver in order to use SimpleIDE.
3. Click on the link to download SimpleIDE 1.0 RC2 for MAC. Follow all the instructions to download and install SimpleIDE.
4. STOP where it says "Connect your board and run a test program" You cannot run the program yet because you do not have the hardware. We will do that in class.